




XM \bullet -06



XM \bullet -12




XM \bullet -25




1 : Maximum differential - Ecart maxiaux - Maximale hysteresen - Intervalos máximos - Differenziali max - intervalos maximos
 2 : Minimum differential - Ecart miniaux - Minimale hysteresen - Intervalos mínimos - Differenziali min - intervalos minimos

XMx/XMA




XMP





PH : High setting point - Point haut - Oberer Schaltungspunkt - Punto de disparo superior - Punto di scatto superiore - Ponto alto
 PB : Low setting point - Point bas - Unterer Schaltungspunkt - Punto de disparo inferior - Punto di scatto inferiore - Ponto baixo

Setting
 Réglage
 Einstellungen
 Adjustes
 Regolazione
 Reglagem



Fixing bracket
 Equerre de fixation
 Befestigungswinkel
 Escuadra de fijación
 Squadra de fissaggio
 Esquadro de fixação

XMA-ZL001




DANGER / PELIGRO / DANGER		
<p>HAZARDOUS VOLTAGE</p> <p>Disconnect all power before servicing equipment.</p> <p>Electric shock will result in death or serious injury.</p>	<p>TENSION PELIGROSA</p> <p>Desenergice el equipo antes de realizarle servicio.</p> <p>Una descarga eléctrica podrá causar la muerte o lesiones serias.</p>	<p>TENSION DANGEREUSE</p> <p>Couper l'alimentation avant de travailler sur cet appareil.</p> <p>Une électrocution entrainera la mort ou des blessures graves.</p>


<p>FOR XMA\XMx ONLY</p> <p>SCALE MUST BE READ WHEN THE PRODUCT IS NOT TRIPPED</p>	<p>EXAMPLE EXEMPLE ESEMPIO</p> <p>PRECISION: ±10% PRECISION: ±10% PRECISION: ±10%</p>
<p>SEULEMENT POUR XMA\XMx</p>	
<p>LECTURE DE L'ECHELLE A EFFECTUER AVEC PRODUIT NON ENCLANCHE</p>	
<p>SOLO PER XMA\XMx</p>	
<p>LETTURA ETICHETTA DA EFFETTUARE CON PRODOTTO A RIPOSO</p>	

Pressure switches
 Pressostats
 Druckwächter
 Presostatos
 Pressostati
 Pressostatos


XMX



XMA



XMP









Dimensions - Encombrements - Abmessungen - Dimensiones - Dimensioni - Atravancamentos

XMX/XMP-A06●21●●/A12●21●●

XMX/XMP-A06●24●●/A12●24●●







XMX/XMP-A25●21●●



XMA-●06●21●●/XMA-●12●21●●

XMA-●06●24●●/XMA-●12●24●●

XMA-●25●21●●







XMP-B/C●●●●●●●●

XMP-D/E06/12●●●●●●

XMP-R06/12●●●●●●

XMP-R25●●●●●●



XMXXMAXMP

